

C O N T R O L L E R I N F O R M A T I O N S H E E T

Maple Model(s)	PLC or Controller
HMI5000 Series	GE Intelligent Platforms Series 90 and VersaMax



Summary

Maple Systems' **HMI5000 Series** Human/Machine Interface Terminals (Maple HMIs) communicate with GE Intelligent Platforms Series 90 and VersaMax PLCs using the SNP-X protocol. The GE PLC communication protocol must be set for SNP; in later versions of firmware the SNP protocol includes SNP-X which is what is actually used by the HMIs. When configured with EZware-5000, the Maple HMI is the master in a point-to-point single master, multiple slave format. Please refer to the HMI5000 Series Programming Manual for information on connecting multiple Maple HMIs to a single PLC port.

Compatible PLCs

PLC Family	PLC Model
Series 90-30	311, 313, 323, 331, 340, 341, 351, 352, 363, 364, CMM311
Series 90-70	CMM711
Series 90 Micro	IC693UDR005, IC693UAL006, IC693UAA007, IC693UDR010 (if firmware version 3.01 or later is used which includes the SNP-X protocol)
VersaMax	CPU001, 002, 005, E05, 10pt Nano, 14-28pt Micro

Communications Cable

For the Series 90-30, the Maple HMI can be connected to:

- The main SNP communications port located on the power supply module
- The CPU may have an RS232 or RS485 port that can be set up for SNP, this depends upon model CPU selected
- The Port 1 or 2 on the CMM311 communications coprocessor module Wye cable, must be set up for SNP (the CMM311 is for the Series 90-30).

For the Series 90-70, the Maple HMI can be connected to:

- The port on the CMM711 communications coprocessor module which must be set up for SNP (the CMM711 is for the Series 90-70). Note, for the Series 90-70 PLC's, only the CMM711 communications module supports the SNP-X protocol needed to communicate with the HMI5000 Series HMI's.

For the VersaMax, the Maple HMI can be connected to:

- Port1 (via RS-232) located on the power supply module or main CPU of the PLC, set for SNP protocol
- Port2 (via RS-485) located on the power supply or main CPU.

A list of communications cables offered by Maple Systems as well as cable assembly instructions to assist you in assembling your own communications cable are available on our website at www.maplesystems.com.

WARNING *If your communications cable is not wired exactly as shown in our cable assembly instructions, damage to the HMI or loss of communications can result.*

PLC Settings

The Modem Turnaround Delay must be set to 0.
The Level 2 Password in the PLC must be set to NULL.
The port used must be set for SNP and the processor must use firmware version “S” or newer, which includes the SNP-X protocol.
The SNP-X port’s Baud Rate, Parity, Data Bits, and Stop Bits settings must match the settings in EZware-5000.

Accessible PLC Memory

Register Memory

The following table lists the PLC’s register memory ranges that the Maple HMIs are able to access. Please note that your PLC’s memory range may be *smaller* or *larger* than that supported by these HMIs. The following register memory can be displayed in 16, or 32-bit format on the Maple HMI.

(Note: d=decimal)

PLC Register Type	Address Range	Format	PLC Register Description
%R	1-10000	dddd	Data Memory Registers
%AI	1-10000	dddd	Analog Input Registers
%AQ	1-10000	dddd	Analog Output Registers

Discrete Memory

The following table lists the PLC's discrete memory ranges that the Maple HMIs are able to access. Please note that your PLC's memory range may be *smaller* or *larger* than that supported by these HMIs. The following discrete memory is displayable in single-bit format on the Maple HMI.

(Note: d=decimal)

PLC Bit Type	Address Range	Format	PLC Bit Description
%M	1-10000	dddd	Discrete Internals
%I	1-10000	dddd	Discrete Inputs
%Q	1-10000	dddd	Discrete Outputs

Memory Not Supported

The following PLC memory areas are not currently supported by the Maple HMIs:

- %T (Discrete Temporaries)
- %SA (SA Status Discretes)
- %SB (SB Status Discretes)
- %SC (SC Status Discretes)
- %S (S Status Discretes)
- %G (Genius Global Data)

Important Memory Considerations

If your PLC's memory range is smaller than the range supported by the Maple HMIs, it is possible to configure the HMI to monitor a PLC memory address which does not exist. Since this can cause unpredictable results, when you configure the HMI please ensure that all selected PLC memory addresses are valid for your PLC model.

Do not configure the HMI to write to any PLC memory address which should only be written to by the PLC.

EZware Settings

The following table lists the communications settings that must be configured in EZware. These settings can be found in the *Edit-System Parameters* menu under the *Device* tab. Please note:

- The **Recommended Settings** column provides the recommended setting based upon the default settings most commonly used in the GE Intelligent Platforms Series 90 and VersaMax PLCs. The available port may determine whether RS-232 or RS-485 should be used.
- The **Options** column lists EZware's options; your PLC may not support every option.

Name	Recommended Settings	Options	Important Notes
Name:	GE Intelligent Platforms SNP-X		
HMI or PLC	PLC		
Location	Local	Local, Remote	Select <i>Local</i> if PLC directly connected to HMI, <i>Remote</i> if PLC connected thru another HMI.
PLC type	GE Intelligent Platforms SNP-X		
PLC I/F:	RS-485	RS-232, RS-485 2W, RS-485 4W, Ethernet	Must match the SNP-X port setting.
PLC default station no.:	1	0-255	Not Used
Settings: COM:	COM 1	COM1-COM3	Serial port of HMI connected to PLC.
Settings: Baud rate:	19200	4800, 9600, 19200, 38400, 57600, 115200	Must match the SNP-X port setting. Use the fastest baud rate supported by the PLC.
Settings: Data bits:	8	7 or 8	Must match the SNP-X port setting.
Settings: Stop bits:	1	1 or 2	Must match the SNP-X port setting.
Settings: Parity:	Odd	Even, Odd, None	Must match the SNP-X port setting.
Settings: Timeout (sec)	1.0	0.1 to 25.5	Adjust if longer timeout is required.
Settings: Turn around delay (ms)	0	0-1000	Timeout period between HMI polls.
Settings: Send ACK Delay:	0		Not Applicable
Settings: Parameter 1:	0		Not Applicable

Name	Recommended Settings	Options	Important Notes
Settings: Parameter 2:	0		Not Applicable
Settings: Parameter 3:	0		Not Applicable
Interval of block pack words	5	0-512	See <i>HMI5000 Series Programming Manual</i> (Maple p/n 1010-1007)
Max. read-command size (words):			Not Adjustable
Max. write-command size (words):			Not Adjustable